



**NAR Labs** 國家實驗研究院

**台灣半導體研究中心**

Taiwan Semiconductor Research Institute

MEMS Fabrication & Sensors developed in TSRI

Han-Ting Hsueh

承諾·熱情·創新


[www.narlabs.org.tw](http://www.narlabs.org.tw)  
[www.tsri.org.tw](http://www.tsri.org.tw)

# Gas Sensor

## Ambient air monitoring

**NAR Labs**

承諾 · 熱情 · 創新




### Metal Oxide Semiconductor MEMS Gas Sensor

1. Micrographics
2. Low Power Consumption.
3. Multi-Gas Sensor Improve Accuracy.

### Device Application:

1. Wi-Fi 、Bluetooth for Personal Safety.
2. Environment Safety for Smart Home.
3. Air Quality for Air Freshener.




# TSRI MEMS Gas Sensor

**NAR Labs**


承諾 · 熱情 · 創新



Micro-Heating Zone  
120  $\mu\text{m}$



Hair's Width :  
75-76  $\mu\text{m}$



- ✓ **MEMS Technology (Miniaturization)** : The sensing chip is miniature to pinhole size and the micro-heated area has only one hair width.
- ✓ **Low Stress Membrane & Micro-heater Technology (Rapid Heating)** : It takes about milliseconds(ms) heating to 320°C.
- ✓ **Nanotechnology (Energy Saving)** : Improve Response, Sensitivity and Low power consumption with Sensor.

# Stability of the Micro-Heater

**NAR Labs**

承諾 · 熱情 · 創新

## 6" gas sensor Structure


Nano particles  
or  
Nano porous

Sensing Film




Micro Heater  
& IDE

Low Stress Dielectric  
Layer



Suspension Structure



In metal oxide gas sensors, micro-heater is used as a hot plate which controls the temperature of the sensing layer.



Prevent Oxidation of Metal Electrodes





# Gas Sensors Characteristics


**NAR Labs**

承諾 · 熱情 · 創新


## TVOCs



## Performance and power consumption



## Stability



## Power Consumption

|                              | Narlabs-TSRI    | Company-A      | Company-B  |
|------------------------------|-----------------|----------------|------------|
| Chip size (mm <sup>2</sup> ) | 0.65 x 0.65     | 0.75 x 0.5     | NA         |
| Package (mm <sup>3</sup> )   | ~3.2 x 2.35 x 1 | ~3.2 x 2.5 x 1 | ~3 x 2 x 1 |
| Power consumption            | 10~15 mW        | 15 mW          | ~30mW      |

Gas sensing: Alcohol, CO, TVOCs, NO<sub>x</sub>, NH<sub>3</sub>, C<sub>4</sub>H<sub>10</sub>

# Gas Sensors Characteristics

**NAR Labs**

承諾・熱情・創新

## Cross-Sensitivity

### CO / C<sub>2</sub>H<sub>5</sub>OH

| Gas sensor        | CO                               | C <sub>2</sub> H <sub>5</sub> OH |
|-------------------|----------------------------------|----------------------------------|
| Operating Voltage | V <sub>H</sub> :1.2V<br>(~150°C) | V <sub>H</sub> :3V<br>(~330°C)   |

### CO / C<sub>4</sub>H<sub>10</sub>


| Gas sensor        | CO                               | C <sub>4</sub> H <sub>10</sub> |
|-------------------|----------------------------------|--------------------------------|
| Operating Voltage | V <sub>H</sub> :1.2V<br>(~150°C) | V <sub>H</sub> :3V<br>(~330°C) |

### NO<sub>x</sub> / SO<sub>x</sub>

| Gas sensor        | NO <sub>x</sub>                  | SO <sub>x</sub>                  |
|-------------------|----------------------------------|----------------------------------|
| Operating Voltage | V <sub>H</sub> :1.2V<br>(~150°C) | V <sub>H</sub> :3.5V<br>(~350°C) |


### Cross Sensitivity-Control Micro-Heater Temperature

Temperature ↑ Response ↑ : TVOCs , SO<sub>2</sub>  
 Temperature ↑ Response ↓ : CO , NO<sub>x</sub>




# Narlabs-TSRI'S Gas Sensing Chip-Module-System

承諾 · 熱情 · 創新




Ten thousand gas sensor pieces  
on one 6" wafer





sesame



Micro-Heating Zone 120  
um





**Package**



3mm

2.35mm



Prototype of CO Sensor  
Embedded Smart Phone




# Breath Sensing

**NAR Labs**

承諾 · 熱情 · 創新


## Asthma



| Adults   |     |              |      |
|----------|-----|--------------|------|
| NO (ppb) | <25 | 26 - 49      | 50+  |
| Range    | Low | Intermediate | High |

| Children (<12 years of age) |     |              |      |
|-----------------------------|-----|--------------|------|
|                             | <20 | 21 - 44      | 45+  |
|                             | Low | Intermediate | High |



# Vibration Sensor

**NAR Labs**

承諾・熱情・創新


## ● Real-time Failure Investigation ?




- Temperature
- Vibration
- Noise

### Abnormal Vibration Detection


**Normal**



**Abnormal**



### Remote Overheating Investigation



# Vibration Sensor

**NAR Labs**

承諾 · 熱情 · 創新

## ● Magnetic Induction Vibration Sensor




Figure 1. Schematic drawing of the FR4 energy harvester.





Figure 5. Photograph of the whole device.

Ref. J. Micromech. Microeng. 19 (2009) 035001





# Vibration Sensor

**NAR Labs**

承諾 · 熱情 · 創新

## ● Device Fabrication

### Vertical Heterogeneous Assembly




~ 2g

~ 0.16 mm<sup>2</sup> (sensor part)


Frequency Detection: 20 ~ 2000Hz

Self-powered Device (Bias-free)




# Vibration Sensor

## ● Device Characterization



**Bias-Free Operation**

**Broadband Vibrating Detection**




**Low g Vibrating Detection**

# Vibration Sensor

## ● Demonstration for Smart Factory

### Demonstration of Dry Pump Vibration Detection by Proposed Vibration Sensor




# Vibration Sensor





**NAR Labs**

承諾 · 熱情 · 創新

## ● Demonstration for Conventional Factory



Vibration Sensor



# Microfluidics and Biosensing Researches in TSRI

承諾·熱情·創新



---

1. Microfluidic chip fabrications and their applications
2. Micro/nano-manipulation and concentration in a biochip
3. **Label-free** and **whole cell** diagnostic assay




# Standard PDMS-based Microchannel Fabrication and Microfluidic Chip with Functional Electrodes

**NAR Labs**


承諾 · 熱情 · 創新



**Microchip**






**Alignment and bonding**




# Microfluidic Gray-Scale Photolithography through the Generation of Concentration Gradient

**NAR Labs**

承諾 · 熱情 · 創新




# Current state of Gray-scale Lithography



Heidelberg Instruments GmbH





<http://www.himt.de/en/technology/gray-scale-lithography.php>



# Flow Rate Effect

**NAR Labs**

承諾 · 熱情 · 創新




10kV X80 100 μm WD 8.0mm

|        |           |
|--------|-----------|
| Width  | 825.15 μm |
| Height | 90.411 μm |

# Light-induced Dielectrophoresis for Passive and continuous Separation of Microparticles

**NAR Labs**

承諾 · 熱情 · 創新




# Dynamic Separation


**NAR Labs**

承諾 · 熱情 · 創新


(a)




(b)



(c)






(d)



# Electrokinetics Enhanced Sensitivity and Selectivity for DNA Hybridization/Immunoassay

**NAR Labs**



承諾 · 熱情 · 創新



# Shear Force Enhanced Specificity

**NAR**Labs

承諾 · 熱情 · 創新



# Whole Cell Diagnosis!

**NAR Labs**

承諾 · 熱情 · 創新



## Rapid On-Chip SERS Identification of Bacteria

**a**


Raman Spectrometer

Raman laser

Selective concentration!



**Minute-level detection speed!**



# Comparing to Current Protocol in General Hospital

**NAR Labs**

承諾 · 熱情 · 創新


## Bacteria detection in hospital



Positive Blood Culture



Plate culture



Biochemical Detection  
(Enterotube II)

24 hr

16-24 hr




Positive Blood Culture



Electrokinetically trapping

5 min






Raman Spectroscopy

~30 sec

# Conventional Turbidimeter and AST Application




承諾 · 熱情 · 創新





# Pre-Concentration Enhanced Sensitivity

NAR Labs

承諾 · 熱情 · 創新






## 3.5 Hours Antimicrobial Susceptibility Testing Assay



- \*Rapid AST of Septicemia and Urethritis
- \*Culture Free
- \*44 hr shorter than current methods
- \*Simple and User Friendly Detection Protocol
- \*Major error < 2% (3/151)

**Tree-steps only!**

**Simple and User Friendly**



Thanks for Your Attention!

